Replacing the Timer Battery in the Kiosk

Required Tools

- **Screwdriver**
- **Wrench or socket tool** (for loosening the nuts, size depends on model)
- **4 × AA batteries** (new)

---

1. Disconnect power

- **Unplug the kiosk** from the power outlet to ensure it is completely powered off.

---

2. Remove the cover

- Use a **wrench or socket tool** to loosen and remove the **4 nuts**.
- Remove the cover carefully.

---

3. Loosen the timer (if required)

- If the timer is mounted tightly:
  - Slightly loosen the **2 nuts** on the left and right side of the timer using the wrench or socket tool.
  - Do **not** remove them completely.

---

4. Remove the timer from the DIN rail

- On the **bottom side** of the timer, locate the **red release knob / lever**.
- Use a screwdriver to **push it downward**.

- Pull the timer **forward** to remove it from the DIN rail.

---

5. Replace the batteries

- On the **back side** of the timer:
  - Replace the **4 AA batteries**.
  - Make sure the **polarity (+ / –)** is correct.

---

6. Reinstall the timer

- Mount the timer back onto the DIN rail and press it firmly into place.
- Tighten the previously loosened nuts using the wrench or socket tool.

---

7. Check connections

- **Before reinstalling the cover**:
  - Check all **connectors and terminals**.
  - If any connectors are loose, gently tighten them with a screwdriver.

---

8. Reinstall the cover

- Put the cover back on and secure it with the **4 nuts**.

---

9. Power on and set mode

- Plug the kiosk back into the power outlet.
- Set the timer switch from **AUTO / MANU** to **ON**.

Revision #2
Created 21 January 2026 18:47:53 by Admin
Updated 21 January 2026 18:48:41 by Admin